

# SKYLINE DESIGN PRODUCT CARE

## DEFINE™ GLASSBOARDS

## FLICK™ PROJECTION GLASSBOARDS




# SKYLINE DESIGN PRODUCT CARE

## DEFINE™ GLASSBOARDS

## FLICK™ PROJECTION GLASSBOARDS

### CLEANING

---



To clean your Skyline Design glassboard, lightly spray the entire surface with a standard non-solvent based, non-abrasive glass cleaner. Gently wipe the surface clean with a lint-free cloth. Use a minimal amount of cleaner and do not allow the cleaner to weep behind the glassboards during cleaning. The frequency of required maintenance is based on usage.

Silk Glassboards (matte finish): Stickers, tape and putty should not be used with Skyline Design Silk glassboards.

### MARKERS

---

Any marker can be used to draw and write on Skyline Design glassboards. For best results, we recommend the use of dry-erase markers. To clean the glass surface, wipe away the dry-erase marker with an eraser or dry cloth. Clean or replace the eraser or dry cloth frequently.

Silk Glassboards: We do not recommend permanent markers for use with Skyline Design Silk boards; however, if used, clean promptly with a standard glass cleaner.



For questions, and to purchase markers & accessories: [glassboards@skydesign.com](mailto:glassboards@skydesign.com)

*Skyline Design offers a limited lifetime warranty on glassboards against manufacturer defect or workmanship. See Terms and Conditions for full warranty.*